



communications

Integrated Optical Systems

New Era of Metal Optics for Visible Applications Bare Be, Bare Al and EN Cladding

C. Duston, J.B. Barentine, K. Carrigan, Marty Kwitek

NASA Mirror Technology Days

Rochester, NY

July 31 – August 2, 2012

Focus on Metal Optics

Motivation: Customers require

- Off-Axis & Aspheric Mirrors
- Faster Delivery
- Lower Costs
- Visible Quality

Single Point Diamond Turning is not sufficient


Integrated Optical Systems solves these challenges
using
Computer Controlled Optical Surfacing (CCOS)

Topics to be Discussed

- Bare Aluminum
- Electroless Nickel Plated Aluminum
- Bare Beryllium

Single-Point Diamond Turning (SPDT) Facility for Large Metal Optics

- Large optics are single-point diamond turned and post-polished
- Ideal environment for high precision machining
 - Floor is de-coupled from acoustic and seismic sources
 - $<0.5^{\circ}\text{C}$ temperature control
 - Existing large-optics handling equipment
- SPDT equipment uniquely modified to accept larger optics
 - Ultra-high precision SPDT up to 700mm \varnothing
- Metrology
 - Three 1.5m Leitz CMMs, numerous smaller



State-of-the-art Metrology and QA




Optical Assembly/Alignment with DMI



Cryo/VAC Optical Test Chambers




Computer Optimized Alignment Station



High Precision LOS Testing



Null Testing of Aspheric Components



Large CMM Inspection Stations



Phase-shifting and white-light interferometric microscope



Stylus Profilometry



Visible & IR Phase Shift Interferometer



BRDF Measurement



PST



Atomic Force Microscope

Topics to be Discussed


- Bare Aluminum
- Electroless Nickel Plated Aluminum
- Bare Beryllium

Aluminum Polishing Results: Surface Quality

2011 Results, RSP RSA 6061-T6


Single-point diamond turning (SPDT) followed by post-polish

4" 6061-T6 Aluminum sample SPDT on Tinsley's Nanotech 350FG



■ SPDT Result

- Surface errors of $\sim 0.250\lambda$ PV & 0.060λ RMS @ 632.8nm
- Surface roughness of $\sim 30\text{\AA}$ RMS
- Surface quality of 40/20
Color is apparent in the surface




● Post-Polish Result

- Surface error deterministically polished to specification
- Surface roughness of $<20\text{\AA}$
- Surface quality of 40/20 or better
No-color remains in the surface


Aluminum Polishing Results: Surface Roughness

2011 Results, RSP RSA 6061-T6

Single-point diamond turning (SPDT) followed by post-polish
 4" 6061-T6 Aluminum sample SPDT'd on Tinsley's Nanotech 350FG




Tinsley - CCOS
 Surfacing



35Å from Diamond Turning Machine (1.4mm field)

15Å rms after Tinsley Surfacing (1.4mm field)




- Polish process is 100% CCOS machine based and highly repeatable
- Polish times are very low, making the process viable on low-cost optics
- Post-polish removes little material, compatible with off-axis mirrors, and maintains SPDT datum to optical surface integrity


Aluminum Polishing Results: Surface Error

2012 Results, Standard 6061-T651

Single-point diamond turning (SPDT) followed by post-polish
4" 6061-T651 Aluminum sample SPDT'd on Tinsley's Nanotech 450UPL




Tinsley Surfacing



Surface Error: $\lambda/3$ PV & $\lambda/18$ RMS (@632.8nm)

Surface Error: $\lambda/9$ PV & $\lambda/45$ RMS (@632.8nm)


- Demonstration of highly deterministic polish
- 60% convergence on SPDT surface error residual, done in a matter of hours
- Surface roughness of 20\AA after processing.



$\sim 20\text{\AA}$ after smoothing (1.4mm field)

Application of Bare AI: Telescope Overview


- In April of 2011, Tinsley was solicited for the manufacture of a very short lead-time Aluminum telescope
- Scope of Work:
 - Concurrent Engineering
 - Substrate Manufacture and Testing
 - Finishing of CFM Housing
 - Assembly
 - Final Telescope WF Over Field Testing
- A finished telescope was delivered just 15 weeks from start of order.



Bare Al: Proven Visible Quality Performance

Telescope Wavefront

Focus Plane Within 65µm of Nominal Position




Field Angle = -4.31 deg
RMS = 0.36 wv He-Ne

Field Angle = 0 deg
RMS = 0.30 wv He-Ne

Field Angle = 4.43 deg
RMS = 0.39 wv He-Ne

Mirror Surface Roughness

All optics <20Å, 1.4 x 1.4mm Field Nyquist Filtered



Fold Mirror
12.2Å RMS

Primary Mirror
19.9Å RMS

Secondary Mirror
18.9Å RMS

Tertiary Mirror
19.4Å RMS





Topics to be Discussed


- Bare Aluminum
- **Electroless Nickel Plated Aluminum**
- Bare Beryllium

Super Polish of Nickel Results: Single-Point Diamond Turning followed by CCOS

Super polish of Nickel that effectively addresses all spatial period ranges




Super Polish of Nickel Results: Versus Silicon




Super-polished Nickel

Spatial Frequency

Super-polished Silicon




Super Polish of Nickel Results: PSD Comparison to Silicon




Topics to be Discussed

- Bare Aluminum
- Electroless Nickel Plated Aluminum
- **Bare Beryllium**

Bare Beryllium: I-70 Production Aspheres



Primary Mirror Surface Error: 0.031λ RMS (@632.8nm)



Primary Mirror Surface Roughness: 17.5Å RMS (1.0mm Field)



- I-70 Beryllium provides a more readily available and economical alternative to O-30
- IOS has made more than eighty (80) production aspheres in I-70 over the past 5 years

James Webb Space Telescope

Primary Mirror Segment



Secondary Mirror





Tertiary Mirror



Fine Steering Mirror



Rear side view of mirrors showing relative size



Secondary Mirror


18 segment Primary Mirror

Cryo-null figuring: Requirements and Results

Mirror Performance Parameter	Specification	Tolerance	Average Final Performance	Average Margin %
Clear Aperture (CA) Area	1.47 m ²	Minimum	1.47 m ²	0%
Mid. Frequency SFE (spatial period range: CA to 222 mm)	20 nm RMS	Maximum	12.3 nm RMS	38%
High Frequency SFE (spatial period range: 222 mm to 0.080mm)	7 nm RMS	Maximum	6.1 nm RMS	13%
Surface Roughness	4 nm RMS	Maximum	3.2 nm RMS	20%


IOS polished 30m² of bare beryllium mirrors for JWST – **twice !**

Power Spectral Density (PSD) Sample PM (Overlapping Curves)







Optical Performance of deliverable mirrors

Spare Mirrors



Flight Mirrors



SURFACE FIGURE ERROR
 Total PM Composite: 13.5 nm RMS
 Telescope PM Target: 21.2 nm RMS

Conclusion – Visible Quality Metal Mirrors = Reality



- L-3 IOS has made Visible Quality Metal Mirrors a reality using Computer Controlled Optical Surfacing
- CCOS is fast and deterministic, without losing the benefits of SPDT
 - Visible quality finish & figure
 - Snap-Together tolerances for fast, precision assembly
- Demonstrated CCOS on wide variety of metals
 - Visible quality, passively athermal imaging achieved
 - bare Aluminum
 - bare Beryllium
 - Nickel-plated super-polish allows a variety of substrate materials to be used
 - Aluminum, Beryllium, AlSiC, AlSi, AlBeMet, Stainless Steel, etc.

